AV-USB Video Capture User Manual

Key Features

- Supports AV full format video input: NTSC and PAL
- Supports S-Video full format video input: NTSC and PAL
- Automatic format & interface detection
- Supports Brightness/Contrast/Saturation/Hue adjustment
- Supports both MJPEG and YUV422 output mode
- Compliant with USB Video Class standard
- Compliant with USB Audio Class standard
- Supports external audio ADC
- Capture Video & Audio through USB 2.0 interface
- Portable and easy to store.
- Plug & play
- Support most of the formats: record in DVD+/-R/RW, DVD+/-VR, and DVD-Video.
- Can be used for internet conference / net meeting

Specifications

- USB 2.0 high speed
- MJPEG mode output resolutions:
 - 720×480@50Hz/30Hz/20Hz/10Hz
 - 640×480@50Hz/30Hz/20Hz/10Hz
 - 480×320@30Hz
- YUV422 mode output resolution:

480×320@30Hz

Video input: Video Input: One RCA composite, One S-Video

- Audio input: Stereo audio (RCA)
- Dimension(L*W*H): ca. 90 x 28 x 14mm
- Power: USB bus power, 5V/160mA

System Requirements

- USB: Compliant with USB 2.0 free port
- OS: Windows 2000, XP, Vista, WIN7, Win10, MAC OS
- CPU: Intel Pentium 4 or higher
- Hard Disk: 1GB of available hard drive space for program installation, 4GB+ hard drive space for video capture and editing
- Memory (RAM): 256MB (512MB or more)
- Support Capture Software: honestech HD DVR3.0, OBS Studio, Potplayer, AmCAP, VLC, Quick Time Player (MAC OS)

Package Contents

- IU032A AV-USB Capture card 1 pc
- User Manual 1 pc

Operating instructions for OBS Studio under windows system

Device connection

1. Plug the USB Type-A(USB2.0) male of the capture card to the USB2.0 port of PC, if there are "USB Video Device" and "USB2.0 MIC" showed in the list of Device Manager of the PC. It means the capture card has connected to the PC. See picture below:



2. Then connect video device (input source) to the capture card by RCA/S-Video cable.



Video Capture and recording via OBS Studio

- 1. Download the OBS Studio software from the website, obsproject.com, then install it on the PC.
- Open the OBS Studio software, click on the "+" button under the "source" window, select "Video Capture Device" in the pop-up menu, pop-up "create/select source" window, enter a name in the "Create new" box and click "OK" button, the pop-up properties configuration dialog.



S Create/Select Source		?	×
• Create new			
AV-USB Capture			
○ Add Existing			
🗹 Make source visible			
	OK	Cano	cel

- 3. Then set the properties for the video you're going to capture in the pop-up window;
 - a) Select "AV-USB 2.0" from the optional list of "Device"; And set different resolution in the "Resolution/FPS type" box;

Properties for 'Video Capture Device 1'	?	×
Wiisports Image: Construction of the second sec		
Device AV TO USE2.0 HP HD Camera AV TO USE2.0		
Configure Video		
Configure Crossbar		
Resolution/FPS Type Custom		61
Resolution 480x320		

- b) For YUY2 output video format, the resolution should be set "480*320"; If select other resolution, then only "MJPEG" or "ANY" two output video formats could be available.
- c) For "Audio Output Mode", select "Output desktop audio (DirectSound)", and select "Use custom audio device"
- d) For Audio device, select "USB 2.0 MIC"

Properties for 'AV-	USB Capture'	?	×
	(VIISports) $(VIISports)$		
Resolution/FPS Type	Custon	•	-
Kesolution gac	(200900) Watch Detwork RPS (antonalast: 50)		1
Video Format			
YUV Color Space	Default		
YUV Color Ranze	Partial		
Buffering	Auto-Detect		ā
	□ Flip Vertically		
Audio Output Mode	Output desktop audio (DirectSound)		-
	🗹 Use ouston audio device		
Audio Device	麦克凤 (USE2.0 MIC)		а,
Defaults	OK	Can	rel

See picture below:

- 4. To synchronize the audio and video, it is required to set the video delay, see below operations:
 - a) right-click "Video capture device", select "Filter", then click "+" from the pop-up window, then select "video delay(asynchronization)" as shown in below pictures:

1. 2. 3. 3.		16		() Fi	ters for 'AV-USB Capture'
ニュースチャンネル	Add		•	Audio	/Video Filters
N.S. B.	Сору	Ctrl+	c		
-	Paste (Reference)	Ctrl+	v		
PM U	Paste (Duplicate)				
0 7	Copy Filters				
6-7	Paste Filters				
	Rename				
	e Remove	Del			
	Order		•		
	Transform		•		
	Hide in Mixer				
	Deinterlacing		•	+	- ^ ~
	Scale Filtering		•		Compressor
	Fullscreen Projector (Source)		•		Gain
	Windowed Projector (Source)			Noise Gate
					Noise Suppression
	Interact				VST 2.x Plug-in
	Filters				Video Delay (Async)

b) In the new pop-up window, enter 470MS. (it is required to adjust the value according to the situation until you find the audio and video synchronization), as shown in below picture:

Filters for 'AV-USB Capture'	? ×
Audio/Video Filters	
♥ Video Dalay (Anyno) + ∧ ∨ Effect Filters	Image: Second definition of the second d
$+ - \land \lor$	Defaults Close

- 5. Start to Video Recording
 - a.) Click the "Settings", choose "Output" and setting your need e.g. Recording Path, then click "Apply"; choose "Audio" "Video" and setting your needs, then click "Apply". See picture below:

		Scene Transitions		Controls	
). O dB 📄 🛛 Fade			Start Streaming	
-10 -5		+	- 8	Start Recording	
) 🜩 🛛 Duration 30	י וחשק		Studio Mode	
-	inf dB		Ň	Settings	
-io -5) ф). 0 dв			Exit	
) Settings				? >	×
General	Output Mode	Simple		•	1
	Streaming				
Stream	Video Bit	rate 2500			
Output	Audio Bit	rate 96		· · · · · · · · · · · · · · · · · · ·	
Audio		Enable Advanced Encoder Setti	ngs vate limits		
	Encoder Preset (higher = less	CPU) veryfast		•	
Video	Custom Encoder Sett	ings]
Hotkeys	Recording Recording Path	C:\Users\Administrator\Videos		Browse	
Advanced		Generate File Name without Space			
*	Recording Quality Recording Format	Same as stream mp4		•	
	Custom Muxer Settings				1
		Enable Replay Buffer			
	Warning: Recordings saved BSODs, power losses, etc. recording to mp4 after it	to MP4 will be unrecoverable if). If you want to record aultipl is finished (File->Remux Record	the file cam e andio track ings)	not be finalized (e.g. as a result of s consider using MKV and remux the	
				OK Cancel Annly	

Settings				? ×
Genera	al Base (Canva	as) Resolution [1280×720	~
	Uutput (Scale	ed) Kesolution	852x480	~
Stream	Dow	vnscale filter	Bicubic (Sharpened Scaling, 16 Samples)	-
A	Common FIS	Values 🔻	80	•
Output				
Audio				
Video				
Hotkey	/5			
Ö. Advanc	ed			
~ Q				
			OK Cancel	Apply
Settings			7	× ×
Settings			?	2 ×
Settings	eral	Sample Rate	7 48khz	• ×
Settings	eral	Sample Rate Channels	28khr Stereo 7 6 2 1	• ×
Settings	aral Deskto	Sample Rate Channels op Audio Device	? 48khz Stereo Default ri.ll.d	2 ×
Settings	eral am Deskto Mic Amilia	Sample Rate Channels op Audio Device Audio Device 2 cu Audio Device 2	? 48khr Stereo Default Disabled Default	2 ×
Settings	eral am Deskto Desktop Mic/Auxiliar Mic/Auxiliary	Sample Rate Channels op Audio Device Audio Device 2 ry Audio Device 2 Audio Device 2	? 48khz Stereo Default Disabled Default Disabled	2 ×
Settings Gene Strea Outp	eral Deskto Desktop but Mic/Auxiliar Mic/Auxiliary o Mic/Auxiliary	Sample Rate Channels op Audio Device Audio Device 2 cy Audio Device Audio Device 2 Audio Device 3	? 48khz Stereo Default Disabled Disabled Disabled	2 × • • •
Settings Gene Strea Outp Audio	o Desktop Desktop Mic/Auxiliar Mic/Auxiliary	Sample Rate Channels op Audio Device Audio Device 2 Audio Device Audio Device 3 Audio Device 3 audio Device 3	7 48khr Stereo Default Disabled Disabled Disabled Disabled	· · · · · · · · · · · · · · · · · · ·
Settings Gene Strea Outp Mudic	eral Deskto Desktop out Mio/Auxiliar Mio/Auxiliary o Mio/Auxiliary o AV-USB Captur	Sample Rate Channels op Audio Device Audio Device 2 Audio Device 3 Audio Device 3 re Enable Pur Funk-tormute	7 48khr Stereo Default Disabled Default Disabled Disabled Disabled dlay 0 ns	
Settings Gene Strea Outp Mudic	eral Deskto Desktop Mio/Auxiliar Mio/Auxiliary Mio/Auxiliary Nio/Auxiliary	Sample Rate Channels op Audio Device Audio Device 2 ry Audio Device 2 Audio Device 3 are Enable Fur Push-to-mute Dush-to-mute Nush-to-talk	48khr Stereo Default Disabled Default Disabled Disabled dlay [0] ms ah-to-talk delay [0] ms	
Settings Gene Strea Outp Outp Video Hotk	eral Deskto Desktop Mic/Auxiliar Mic/Auxiliary o Mic/Auxiliary o AV-USB Captur o	Sample Rate Channels op Audio Device Audio Device 2 ry Audio Device 2 Audio Device 3 audio Device 3 re Enable Pur Fush-to-mute Enable Pur Fush-to-talk	48khz Stereo Default Disabled Disabled Disabled Disabled dalwj 0 as ach-to-mute dalwj 0 as ach-to-mute	
Settings Gene Strea Outp Outp Video Hotk	eral Deskto Desktop Mic/Auxiliary o Mic/Auxiliary o Mic/Auxiliary o Mic/Auxiliary	Sample Rate Channels op Audio Device Audio Device 2 ry Audio Device 3 Audio Device 3 re Enable Fur Push-to-mute Enable Fur Push-to-talk Enable Fur Push-to-mute	48khz Stereo Default Disabled Disabled Disabled Disabled dalay [0 ms sh-to-mute dalay [0 ms sh-to-mute dalay [0 ms	
Settings Gene Strea Outp Outp Video Hotku	eral Desktop mut Mio/Auxiliary out Mio/Auxiliary o Mio/Auxiliary o Mio/Auxiliary averys g克良风/Aux	Sample Rate Channels Op Audio Device Audio Device 2 ry Audio Device 3 Audio Device 3 re Enable Fur Push-to-mute Enable Fur Push-to-talk Enable Fur Push-to-talk Push-to-talk	48khz Stereo Default Disabled Disabled Disabled Disabled datay [0] ns ah-to-talk datay [0] ns	
Settings Gene Strea Outp Outp Mideo Video Hotku	eral Desktop mut Mic/Auxiliary out Mic/Auxiliary o Mic/Auxiliary o Mic/Auxiliary co Mic/Auxiliary o Mic/Auxiliary	Sample Rate Channels op Audio Device 2 Audio Device 2 Audio Device 3 re Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-talk Enable Pur Push-to-talk	48khz Stereo Default Disabled Disabled Disabled Disabled dalay [0] ns sh-to-talk dalay [0] ns sh-to-talk dalay [0] ns sh-to-talk dalay [0] ns	
Settings Gene Composition Comp	eral Desktop Desktop out Mic/Auxiliary out Mic/Auxiliary o Mic/Auxiliary o Mic/Auxiliary o Septon ceys Septon ceys AV-USB Captur Septon chataen	Sample Rate Channels op Audio Device Audio Device 2 Audio Device 3 Audio Device 3 re Enable Fur Push-to-mute Enable Fur Push-to-talk Enable Fur Push-to-talk Enable Fur Push-to-talk Enable Fur Push-to-talk	48khz Stereo Default Disabled Disabled Disabled bisabled dalay 0 ms sh-to-tulk dalay 0 ms	
Settings Gene Composition Comp	eral Deskto Dasktop out Mic/Auxiliary o Mic/Auxiliary o Mic/Auxiliary o Mic/Auxiliary o Mic/Auxiliary hic/Auxiliary AV-USB Captur 支克风/Aux	Sample Rate Channels op Audio Device 2 Audio Device 2 Audio Device 3 Audio Device 3 Tre Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-talk	48khr Stereo Default Disabled Disabled Disabled dalay [0] ms h-to-talk dalay [0] ms sh-to-talk dalay [0] ms	
Settings Gene Composition Comp	eral Deskto Desktop out Mio/Auxiliary o Mio/Auxiliary o Mio/Auxiliary o Mio/Auxiliary o Mio/Auxiliary AV-USB Captur o 支克风/Aux	Sample Rate Channels op Audio Device 2 Audio Device 2 Audio Device 3 Audio Device 3 Tre Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Fush-to-mute Enable Fur Push-to-mute Enable Fur Fush-to-mute Fush-to-talk	48khr Stereo Default Disabled Disabled Disabled dalay [0] ms ah-to-talk dalay [0] ms ah-to-talk dalay [0] ms ah-to-talk dalay [0] ms	
Settings Gene Composition Comp	eral Deskto Desktop nut Mio/Auxiliary o Mio/Auxiliary o Mio/Auxiliary AV-USB Captur ceys 2 ceys 2 ceys 2 ceys 2 ceys 2 cey 2 ce 2 ce 2 ce 2 ce 2 ce 2 ce 2 ce 2 ce	Sample Rate Channels op Audio Device 2 Audio Device 2 Audio Device 3 Audio Device 3 Tre Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Push-to-mute Push-to-talk	48khr Stereo Default Disabled Disabled Disabled bisabled dalay () ms ch-to-mute dalay () ms ch-to-talk ch-to-talk	
Settings Gene Strea Outp Outp Video Hotka	eral Deskto Desktop nut Mio/Auxiliary o Mio/Auxiliary o Mio/Auxiliary AV-USB Captur o 麦克风/Aux	Sample Rate Channels op Audio Device 2 Audio Device 2 Audio Device 2 Audio Device 3 Tre Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-talk	48khr Stereo Default Disabled Disabled Disabled dalay [0] ns aday [0] ns	
Settings Gene Strea Outp Outp Video Hotk	eral Desktop Desktop nut Nii o/Auxili ary o Mii o/Auxili ary o Mio/Auxili ary AV-USB Captur seys 麦克风/Aux	Sample Rate Channels op Audio Device 2 Audio Device 2 Audio Device 2 Audio Device 3 Tre Enable Pur Push-to-mute Enable Pur Push-to-talk Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-talk	48khr Stereo Default Disabled Disabled Disabled ah-to-tute dalay [0] ms ah-to-talk dalay [0] ms	
Settings Gene Strea Outp Outp Video Hotke	eral Deskto Desktop Mic/Auxiliary out Mic/Auxiliary out Mic/Auxiliary out AV-USB Captur anced 占式音响	Sample Rate Channels Op Audio Device 2 Audio Device 2 Audio Device 3 Tre Enable Pur Push-to-mute Denable Pur Push-to-talk Enable Pur Push-to-talk Denable Pur Push-to-talk Denable Pur Push-to-mute Enable Pur Push-to-mute Denable Pur Push-to-mute Enable Pur Push-to-talk	48khz Stereo Default Disabled Disabled Disabled Disabled Actornute dalay [0] ns Actornute Aday [0] ns Actornute Aday [0] ns Actornute Aday [0] ns	
Settings Gene Strea Outp Outp Mideo Hotke	eral Deskto Desktop Mic/Auxiliary out Mic/Auxiliary out Mic/Auxiliary a out AV-USB Captur a b c c c c c c c c c c c c c c c c c c	Sample Rate Channels op Audio Device Audio Device 2 ry Audio Device 3 re Enable Pur Push-to-mute Brable Pur Push-to-talk Enable Pur Push-to-talk Denable Pur Push-to-talk Denable Pur Push-to-talk Denable Pur Push-to-talk	48khz Stereo Default Disabled Disabled Disabled Ally O ms ah-to-mate delay O ms ah-to-talk	
Settings Gene Strea Outp Mideo Video Hotka	eral Deskto Desktop Mic/Auxiliary out Mic/Auxiliary out AV-USB Captur anced 台式音响	Sample Rate Channels op Audio Device Audio Device 2 ry Audio Device 3 audio Device 3 re Enable Fun Push-to-mute Denable Fun Push-to-talk Denable Fun Push-to-talk Denable Fun Push-to-talk Denable Fun Push-to-mute Enable Fun Push-to-talk	48khz Stereo Default Disabled Disabled Disabled Adlay (0 ns	
Settings Gene Strea Outp Mideo Video Hotka	eral Deskto Desktop Mic/Auxiliary out Mic/Auxiliary out Mic/Auxiliary out Mic/Auxiliary AV-USB Captur anced A	Sample Rate Channels Op Audio Device 2 Audio Device 2 Audio Device 3 Tre Enable Pur Push-to-mute Denable Pur Push-to-talk Enable Pur Push-to-talk Enable Pur Push-to-talk Enable Pur Push-to-talk	48khz Stereo Default Disabled Disabled Disabled h-to-mute dalay 0 ns ch-to-talk dalay 0 ns ch-to-talk dalay 0 ns ch-to-talk dalay 0 ns ch-to-talk dalay 0 ns ch-to-talk dalay 0 ns	
Settings Gene Composition Comp	eral Desktop Desktop Mic/Awiliary o Mic/Awiliary o Mic/Awiliary AV-USB Captu appending 合式音响	Sample Rate Channels op Audio Device 2 Audio Device 2 Audio Device 3 Tre Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-mute Enable Fur Push-to-talk	48khr Stereo Default Disabled Disabled Disabled dalay () ns ah-to-nute dalay () ns ah-to-talk dalay () ns ah-to-talk dalay () ns ah-to-talk dalay () ns ah-to-talk dalay () ns	
Settings Gene Construction Cons	eral Deskto Desktop uut Mio/Auxiliary o Mio/Auxiliary o Schor evys Schor inced 台式音响	Sample Rate Channels op Audio Device 2 Audio Device 2 Audio Device 3 andio Device 3 re Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Enable Pur Push-to-mute Push-to-mute Push-to-mute Push-to-mute Push-to-talk	28khz Stereo Default Disabled Disabled Disabled Adlay 0 ms ah-to-talk dalay 0 ms ah-to-talk dalay 0 ms ah-to-talk	

b.) Then click "Start Recording" to record/capture the video.



6. Network Broadcast

a.) Click "Settings" and choose "Stream" to setting your need, then click "OK".





b.) Click "Start Steaming" to stream video.

	Scene Transitions			Controls	
Fade				Start Streaming	
		+ -	¢	Start Recording	
Duration	300ms			Studio Mode	
				Settings	
				Exit	

Operating instructions for QuickTime Player under MAC

operation system

1. Open QuickTime Player software on the Mac book/Mac Pro/Mac mini etc.



2. Click "File" from the menu bar, select "New Movie Recording" from the drop-down box



3. Click below button, select "AV TO USB2.0" and "USB2.0 MIC", then click the start button (the red round one) to start recording.



Remark: if there is no "AV TO USB2.0" and "USB2.0 MIC" selection in the list, then please recheck if the video device (input source) has connected with the capture card successfully.

FAQ:

Q1: Why the image does not synchronize with sound? A1: Please solve as 2-D

Q2: How to download OBS?

A2: Please download at http://www.obsproject.com/

Q3: Whether it support other capture software?

A3: Support most capture software, such as Potplayer, XSplit, AMCap, VLC, etc.

Q4: Why does the recorded video have black edges?

A4: Please choose same resolution of input video and OBS setting.

Q5: When capturing the video or game, the video is shaking?

A5: Please try adjusting the colour encoding system, NTSC or PAL; After adjusting the NTSC/PAL, if it doesn't make things better, then please try adjusting the FPS in the capture software, e.g. OBS; If it is NTSC input, then set the FPS in 60Hz; If it is PAL input, then set the FPS in 50Hz, see below picture for more detail: