



# MAVIC PRO

## In the Box

Check that all of the following items are in your package. If any items are missing, please contact DJI™ or your local dealer.

---

Aircraft ×1  
(Intelligent Flight Battery and Gimbal Cover included)




---

Remote Controller ×1



---

Charger ×1



---

Power Cable ×1



---

## Propeller Pair x3



(Mavic Pro)



(Mavic Pro Platinum)

---

## RC Cable



Lightning connector x1



Standard Micro USB connector x1



USB Type-C connector x1

---

## Manuals




- *MAVIC PRO In the Box*
- *MAVIC PRO Quick Start Guide*
- *MAVIC PRO Disclaimer and Safety Guidelines*
- *MAVIC PRO Intelligent Flight Battery Safety Guidelines*

---

## Accessories\*

---

### RC Cable Slider



x2

x2

---

### Gimbal Clamp x1



---

### Micro USB Cable x1



---

### microSD Card x1 (16 GB)



\* Accessories are not covered by warranty.