

TR2010 - FT012 Brushless Racing Boat

Quick Start Guide

1. Please ensure that the battery is fully charged prior to connecting to the FT012 Racing Boat.
2. When the battery is connected to the charger, the Red LED indicator will light up when battery is under charge condition. The Red LED will turn off when the battery is fully charged.
3. Please ensure that the boat is placed on the plastic stand with the propeller pointed away to avoid accidental injury caused by the propeller.
4. Once the battery is fully charged, open the FT012 Boat hull cover and secure the battery with the Velcro strap.
5. Do not connect the battery deans socket (red socket) to the Boats deans plug just as yet.
6. Install the batteries on the remote control.
7. Ensure that the Steering and Throttle trim adjustments are dialled to the centre position.
8. Connect the FT012 rechargeable battery to the Boat.
9. A red LED will begin to flash indicating pairing mode.
10. Quickly turn the remote controller to on position to proceed with the pairing process.
11. The Red LED light will light up solidly to indicate successful pairing.
12. Please ensure that the pairing process is performed quickly so that the Boat does not exit from pairing mode.