

## **TR3085 Remote Control Drone with 720p Camera Recorder**

Before proceeding, please ensure that the Drone has been fully charged. This is achieved by plugging the USB charger to a USB port and the drone. Charging time is approximately 45 minutes.

The remote controller requires 4 x AA Batteries. Please do not mix different types of batteries.

### **Quick Start Guide:**

1. Turn the switch to ON position on the drone (located on the bottom of the drone body)
2. Turn on the remote controller by pressing the On/Off switch located on the center.
3. After two seconds, the drone is paired and ready to fly.

The drone is equipped with a 720p Camera. It is capable of taking High Res Images or HD video.

### **Instructions for use:**

1. Insert the micro SD card to the card slot located on the bottom of the drone (with metal pins facing into the drone).
2. To take High Resolution images, press the Photo/Video shoot button for one second. Photo shoot button is the top button of the left hand cross keypad.
3. To take HD Videos, press the photo/video shoot button for 3 seconds (recording mode is indicated by a flashing red led). Video shoot button is the top button on the left hand cross keypad.
4. To download the photo and video files, remove the Micro SD card and insert to the provided USB Card reader and plug to your laptop or PC.