

TR3280 RC Hexcopter Wi-Fi FPV Drone

Quick Start Guide

1. Please ensure that the TR3280 RC Hexcopter Wi-Fi FPV Drone is fully charged prior to operating.
2. Connect the USB charging cable to a suitable USB source (PC, Laptop, Power Bank or USB 240V Mains Power Charger) to the Rechargeable Battery inside the battery compartment. Charge time is around 30 minutes.
3. Install 2 x AAA batteries into the remote controller.
4. Download the smartphone APP "TECH RC" from the APP store or Google Play. Alternatively, scan the QR code on the side of the box.
5. Once the Hexcopter Wi-Fi FPV Drone is fully charged, connect the Rechargeable battery plug to the wire with socket inside the battery compartment.
6. When the cables are connected, this will turn the TR3280 Hexcopter Wi-Fi FPV Drone On.
7. Turn the remote controller on. The controller will beep twice to confirm pairing process.
8. The smartphone will need to be paired via Wi-Fi to the smartphone device.
9. Go to the smartphones Wi-Fi setting menu and search and select for the Hexcopter Wi-Fi FPV Drone under zz6688xxxxx.
10. Once connected to the Hexcopter Wi-Fi FPV Drone via Wi-Fi, open the TECH RC APP and select VGA.
11. The video stream will be displayed on the smartphone.
12. Secure the Smartphone on the adjustable and folding bracket.
13. To proceed with flying the Hexcopter Wi-Fi FPV Drone, place the left-hand joystick to the bottom left hand corner and the right-hand joystick to the bottom right corner simultaneously.
14. This will initiate the flight sequence and begin to spin the propellers.
15. You may now proceed to fly the drone (indoors only or calm day without any wind outdoors).

Note:

1. The Hexcopter Wi-Fi FPV Drone can be flown directly from the smartphone. This function can be turned on or off by pressing the On/Off prompt on the top right hand corner of the smartphone.